

# PS1X Series


price computing scale/  
communication price computing scale

Patent product , counterfeiting not allowed


OIML Certificate No: R76/2006-NL1-12.28  
Patent number of vibration trigger design: ZL 2009 2 0177204.7  
Multi customers accumulating patent No: ZL 2012 2 0205664.6  
Membrane Key Patent No: ZL 01 2 03361.8  
Insect-proof Patent No.: ZL 03 2 26288.4



## MODEL EXPLICATION



Patent insect-proof design



Waterproof Grade IP53



## Unique functions

- Unique super power-saving design in the world, only 3 D alkaline batteries can drive the scale 2 years (8 hours each day, 30 times each hour, 10 seconds each time) .
- Unique multi customers accumulating function (patent) with five accumulating keys, able to accumulate for five customers at the same time. One piece of scale could equal to five scales.
- Insect-proof design (patent), able to prevent the defect caused by bugs entering into the machine, reducing 80% failure.
- Patent vibration-detected-circuit design, most of the time in super power saving stand-by status(21uA)will enter into working status by any loading(backlight degree 1~7, default 1 degree, 5.5mA).
- Lower cost: 3 D type dry batteries can drive the scale for 2-3 years. The life of traditional lead batteries is only 2 years and need professional people to replace, expensive and often break down.
- High-sensitive light touch keyboard and super life-long carbon membrane.
- Daily total turnover check function.
- Patent hot keypad (PS1XD with 35\*2 PLU keyboard), not only can be printed to put PLU sheet underneath, but also can be used as unit price default keys, improve sale efficiency.
- The most feature-rich in redisplay function, able to redisplay the transaction process which including unit price, piece weight, total price, price unit and serial number, clearer than other scales in market.
- Patent tempered glass platter, practical, good looking and easy to clean. (Also have the type with stainless steel platter or plastic platter)
- Super 3-line LCD display, able to display weight, unit price and total price in the same screen.
- Well-designed combined function keys, convenience and easy to operate.
- The type with communication port (PS1XC/PS1XD), able to connect with POS or ECR. Optional RS232 dongle to realize wireless communication.

## Excellent functions

- 7 memory unit price key, convenient to operate when busy.
- High anti-interference. The radiation intensity to radio frequency electromagnetic fields up to 10v/m.
- Auto-power saving design, will enter into the stand-by status automatically without any operation (user-defined 4~200 seconds at will, 200 seconds won't enter into auto-power saving status) only consuming 21  $\mu$  A., able to be awake by any loading or operation due to the inner shaking mechanism.(Please tap the platter when there is no response in loading).
- Support backlight (PS1XB/PS1XC/PS1XD) shift function by pressing the backlight key for 1.5 seconds, able to save electric power by turning off backlight in bright area and extend service life of dry battery.
- CHG function, assist users to change notes accuracy.
- Store 70PLU(PS1XD/PS1XF).
- Support price-lock function, suitable to sell weighing commodity of same price.
- Price unit (500g) or kilogram (kg) can be set, suitable to traditional market.
- Two optional ranges: 15kg (e=2g/5g) or 30kg (e=5g/10g).




**ACLAS**<sup>®</sup>  
www.aclas.tw

## Specifications

Model	PS1XB	PS1XF	PS1XC	PS1XD
Basic features	with backlight	with 35*2 hot keys backlight	with backlight	with 35*2 hot keys backlight
Communication Interface	No		RS232 (support power supply)	
Inner resolution	1/30000			
Weight range	0-15-30kg			
power	3pcs D type dry batteries		3 pcs AA type dry batteries	
Battery Life	Approximate 2 year(8 hours each day, 30 times each hour, 10 seconds each time)		3pcs AA batteries (for emergency service)	
Power consumption	soft turning off < 5uA ,stand by: 21uA ,Working :4.6mA; backlight on :<5.5mA			
Working temperature	0°C~40°C			
Working humidity	5%~85%R.H.			
Over loading warning	Over 100.015%			
Over loading protection	Over 120%			
Weight	Net weight: 2kg ; gross weight: 3.5kg			
Platter size	glass platter: 327.4*227.4mm; Stainless steel platter: 330*230mm; plastic platter:230*330mm			

Note : Functions and appearance are subject to change without notice. Please refer to practicality.

## Dimensions



## Wireless communication scale

